


# **Installation Guide**



Fusion KKF2017



KKF2018



## **CAUTION**

Failure to read these instructions prior to installation may result in personal injury, property damage, or product failure. Manufacturer assumes no responsibility for product failure due to improper installation.



## DO NOT RETURN TO STORE

If you have any trouble, contact us before reaching out to the retailer. we'll make it right. Our customer service team will be glad to assist you with any assembly, missing part or questions that you may have about your products.

Contact KIBI **№** 855-883-0888 **Support@kibiusa.com www.kibiusa.com** 

#### **PRIOR TO INSTALLATION**

- 1- For best results, we recommends that this unit be installed by a licensed, professional plumber.
- 2- Please read over these instructions thoroughly before beginning installation. Make sure that you have all tools and supplies needed to complete the installation.
- 3- Please flush the water system to ensure that no metal swarf, solder, and other impurities can enter the faucet that might damage the cartirdge. (Most of the leakages and water flow issues are from avoilding this very necessary step).
- 4-Turn off the hot and cold water lines at the angle valve and turn on the old faucet to release any built-up pressure.
- 5- Keep this booklet and the receipt (or other proof of date and place of purchase) for this product in a safe place. The receipt is required should it be necessary to request warranty parts.
- 6- Please keep the box and packaging materials until your product is completely installed and functional.

## **Cleaning and Care**

Clean the faucet often with a soft cloth to keep it looking like new. For heavy cleaning you can use mild liquid detergents or non-abrasive liquid polisher. Rinse with water and dry with a soft cloth. Avoid abrasive cleaners, steel wool and harsh chemicals as these will dull the finish and void your warranty.

## Tools you may need



Plumbers Tape



Safety Glasses



Phillips Screwdriver

2


Wrench

Silicone sealant


## **Dimensions**

#### Critical dimensions show in mm


#### KKF2017




#### KKF2018




#### KKF2017



#### KKF2018





## **Faucet Installation**




mounting surface.


Note: For first time install, flush the pipes first by open the angel valve to run 60s.









Note: the deck plate need purchase seprately.






the connecting end!

## **Faucet Installation**




Adjust position of faucet body if necessary, Then tighten the mounting nuts with phillips screwdriver until snug.




Connect and tighten the supply hoses by using two adjustable wrenches (avoid twisting or kinking).


Note: Do not remove the net filter that attached into the connecting end!



Turn on water suppliers. Place a bucket below outlet tube, slowly open and close the supply angle valves, **This will prevent debris from being lodged in the hose and sprayer.** 




Shut off water suppliers. Push the handspray hose(A) into the quick connector(B) until you hear a click sound. Make sure it's secured.



suggested installation postion is marked on the hose.

Test the handspray hose. If it does not retract smoothly, reposition the weight.



Turn on the water suppliers, Shut off the faucet and check for leaks.

## **Trouble-Shooting**

If you've followed the instructions carefully and your faucet still does not work properly, take these corrective steps.

Problem	Cause	Action	
Low flow	Aerator or Filter may be clogged	Unscrew aerator to check rubber packing or replace aerator. (Note: some models require wrench to remove aerator.)	
Faucet leaks from under handle	Bonnet nut has come loose or cartridge needs to be reseated	Remove handle and cap. Using a wrench, ensure bonnet nut is tight.	
If leak persists, faucet leaks from spout outlet, water does not shut off completely	Cartridge may need to be adjusted or replaced	SHUT OFF WATER SUPPLIES. Replace cartridge. When reinstalling parts, make sure bonnet nut is tightened securely with a wrench. WARNING: Failure to securely tighten bonnet nut with a wrench could result in water damage.	
Leaking between spray head and the hose	Spray head may be loose or washer is not seated correctly in the hose connection	Tighten spray head by hand until snug. Make sure washer is seated correctly	
Hose does not retract	Weight may be installed incorrectly	Readjust weight on hose	

## **LIMITED LIFETIME WARRANTY**

Thank you for choosing Kibi USA faucets and accessories. We are dedicated to providing you with exceptional products that are built to last. Kibi USA is proud to offer a comprehensive limited lifetime warranty on our kitchen and bathroom faucets and accessories. Here are the details of our warranty policy:

Kibi USA warrants the structure and finish of the faucets and accessories to be free from defects in material and workmanship under normal usage for as long as the original purchaser resides in the residence in which the product was first installed. Additionally, the following warranty periods apply to specific components:

- Sprayhead Assembly: Kibi warrants the sprayhead assembly, including the engine, aerators, structure, restrictors, backflow preventers, sprayer hoses, and braided supply line hoses (nylon, silicon, and stainless steel), to be free from defects in material and workmanship under normal usage for a period of one (1) year from the date of purchase.
- Cartridge: Kibi warrants the faucet's cartridge to be free from defects in material and workmanship under normal usage for a period of five (5) years from the date of purchase.